




A**Replace Graphic Unit**


Secure the roll with the locking key






Remove the screws holding the lid.



Secure the graphic with a piece of velcro or similar.




Lift out the graphic unit.



Put in the replacement graphic unit.



Remove the graphic security



Mount the screws holding the lid.

Remove the locking key and replace it and the hexagonal key underneath the system



Graphic No: 10347

www.expolinc.com

**Panelmått • Panelsizes****Art.nr 4707 Roll-Up 700**

Panel measurement 700mm x 2100mm. Visible height 1950mm.

Art.nr 4700/S4700 Roll-Up 850

Panel measurement 850mm x 2300mm. Visible height 2150mm.

Art.nr 4710/S4710 Roll-Up 1000

Panel measurement 1000mm x 2300mm. Visible height 2150mm.

Art.nr 4705 Roll-Up 1150


Panel measurement 1150mm x 2300mm. Visible height 2150mm.

Art.nr 4775 Supporting rod RU 2450


Panel measurement XXXXmm x 2600mm. Visible height 2450mm.

Maximum panel thickness: 330 µ


ROLL UP
 CLASSIC

A**Preparing and mount the panel**

Remove a small part of the protective liner on the fronttape.
 Fix the panelstrip onto the image and adjust the image towards the strip.
 Remove the remaining part of the protective liner. Press the image firmly onto the panelstrip.
 Turn the image around and do the same thing with the security tape. (Not locking version).




Secure the topprofile with a piece of tape.




Slow down the image with one hand when pulling out the locking key.
 Let the image slowly roll into the system.




Replace the hexagonal key and the locking key underneath the system and make a functioning test.

A**Change the panel**


Pull out the image completely.
 Secure the roll with the locking key.



Take out the roll and remove the existing image by pulling off the roll and the top profile.



Mount the new image as in position 1.



Slow down the image with one hand when pulling out the locking key.
 Let the image slowly roll into the system.

